



Heating □ Air Conditioning

A higher standard of comfort


PCC**C Single Package Cooling Unit

Installation Instructions

*Affix this manual, Specification Sheet and User
Information manual adjacent to the unit.*

Contents

I. Safety Information	2
II. General Information	2
III. Rigging and Handling	3
IV. Duct Connections	3
V. Electrical Wiring	3
VI. Circulating Air and Filters	4
VII. Condensate Drain	7
VIII. Normal Sequence of Operations	7
IX. Startup and Adjustment	7
X. Maintenance	8
XI. Accessories	8



RECOGNIZE THIS SYMBOL AS A SAFETY PRECAUTION.

ATTENTION INSTALLING PERSONNEL

As a professional installer you have an obligation to know the product better than the customer. This includes all safety precautions and related items.

Prior to actual installation, thoroughly familiarize yourself with this Instruction Manual. Pay special attention to all safety warnings. Often during installation or repair it is possible to place yourself in a position which is more hazardous than when the unit is in operation.

Remember, it is your responsibility to install the product safely and to know it well enough to be able to instruct a customer in its safe use.

Safety is a matter of common sense...a matter of thinking before acting. Most dealers have a list of specific good safety practices...follow them.

The precautions listed in this Installation Manual should not supersede existing practices but should be considered as supplemental information.

I. Safety Information

Important

TO THE INSTALLER

Before installing this unit please read this manual and the Specification Sheet to familiarize yourself on the specific items which must be adhered to such as maximum external static pressure to unit, air temperature rise, minimum or maximum CFM and motor speed connections.

TO THE OWNER

It is important to complete the owner registration card and mail it immediately. This will assist Amana in contacting you if any service or warranty information should change in the future. When completing the registration card, be sure to include the Model, Manufacturing and Serial Numbers, plus the installation date.

The warranty certificate is also supplied with the unit. Read the warranty carefully and note what is covered. Keep the warranty certificate in a safe place so you can find it if necessary.

If additional operating instructions are required, call the dealer where the purchase was made. Keep this literature in a safe place for future reference.



WARNING

To prevent death, personal injury or property damage, do NOT use this unit if any part of the unit has been under water. Immediately call a qualified service technician to inspect the unit and to replace any part of the control system which has been under water.



WARNING

**To prevent death, personal injury, or property damage due to improper:
installation
adjustments
alterations
service or
maintenance
consult this manual, the service manual, a
qualified installer, or a service agency.**



WARNING

This product contains or produces a chemical(s) which may cause death or serious illness and which are known by the State of California to cause cancer, birth defects or other reproductive harm.

Unit Placement



WARNING

To prevent death, personal injury, property damage or equipment damage, the following points must be observed when installing the unit.

ALL INSTALLATIONS:

GROUND LEVEL INSTALLATIONS ONLY:

- When the unit is installed on the ground adjacent to the building, a level concrete (or equal) base is recommended. Prepare a base the same physical size as the unit or slightly larger and 3 inches thick.
- The base should also be located where no runoff of water from higher ground can collect in the unit.

ROOFTOP INSTALLATIONS ONLY:

- To avoid possible personal injury or property damage, the roof must have sufficient structural strength to carry the weight of the unit(s) and snow or water loads as required by local codes.
- If horizontal air delivery is used, the unit may be installed directly on wood floors or on Class A, Class B, or Class C roof covering material.
- To avoid possible personal injury, a safe, flat surface for service personnel must be provided.
- If vertical air discharge is used and the unit is installed on combustible flooring or class A, B, or C roofing material, then the Amana roof curb (PRC06* or PRC08*) is required.

II. General Information

This unit is approved only for an outdoor installation.

To assure that your unit operates safely and efficiently, it must be installed, operated, and maintained in accordance with these installation and operating instructions, all local building codes and ordinances.

The heating and cooling capacities of the unit should be greater than or equal to the design heating and cooling loads of the area to be conditioned. The loads should be calculated by an approved method or in accordance with A.S.H.R.A.E. Guide or Manual J - Load Calculations published by the Air Conditioning Contractors of America.

Obtain from:

American National Standards Institute
1430 Broadway
New York, NY 10018

Transportation Damage

All units are securely packed in shipping containers tested according to International Safe Transit Association specifications. The carton should be checked upon arrival for external damage. If damage is found, a request for inspection by carrier agent should be made in writing immediately.

The unit should be carefully inspected upon arrival for damage and bolts or screws which may have loosened in transit. In the event of damage, the consignee should:

1. Make notation on delivery receipt of any visible damage to shipment or container.
2. Notify carrier promptly and request an inspection.
3. In case of concealed damage, carrier should be notified as soon as possible-preferably within 5 days.
4. File the claim with the following supporting documents within the 9 month statute of limitations.
 - a. Original Bill of Lading, certified copy, or indemnity bond.
 - b. Original paid freight bill or indemnity in lieu thereof.
 - c. Original invoice or certified copy thereof, showing trade and other discounts or reductions.
 - d. Copy of the inspection report issued by carrier representative at the time damage is reported to the carrier. The carrier is responsible for making prompt inspection of damage and for a thorough investigation of each claim. The distributor or manufacturer will not accept claims from dealers for transportation damage.

NOTE: When inspecting the unit for transportation damage, remove all packaging materials. Recycle or dispose of the packaging material according to local codes.

III. Rigging and Handling




CAUTION

To prevent property damage, the unit should remain in an upright position during all rigging and moving operations. To facilitate lifting and moving when a crane is used, place the unit in an adequate cable sling.

Important: If using bottom discharge with roof curb, ductwork should be attached to the curb prior to installing the unit. Ductwork dimensions are shown in Amana roof curb installation instructions.

Refer to the Amana Roof Curb Installation Instructions for proper curb installation. Curbing must be installed in compliance with the National Roofing Contractors Association Manual.

Note: Lower unit carefully onto roof mounting curb. While rigging unit, center of gravity may cause condenser end to be lower than supply air end.



**Figure 1
Rigging**

IV. Duct Connections

Horizontal Airflow Installations (24, 30, 36, and 42 Models)

Two three-inch collar connections and two square flanges are shipped with the unit. The collar connections are located in the return air opening of the unit. The square flanges are inside the unit blower compartment. The square flanges can be used for either connecting 16x16 ductwork to the unit or used with a Horizontal Duct Cover kit (CHK001A).

To install the collar connections, remove the two collars, reverse and snap them back into place in the outlet and inlet openings. Be sure the flanges are to the outside of the unit. Secure with screws provided.

Horizontal Airflow Installations (48 and 60 models only)

These units are equipped with 14x14 square supply and return air openings for horizontal air flow. The openings are flanged for ease of duct connection. A 16x16 Horizontal Duct Cover kit (CHK001A) can be used.

V. Electrical Wiring

Thermostat Placement

Thermostat should be mounted 5 feet above the floor, on a vibration free inside wall in a room or a hallway that has good air circulation.

Movement of air should not be obstructed by furniture, door, draperies, etc. The thermostat should not be mounted where it will be affected by drafts, hot or cold water pipes or air ducts in walls, radiant heat from fireplace, lamps, the

sun, television, etc. Consult the Instruction Sheet packaged with thermostat for mounting instructions.



WARNING

To avoid death or personal injury due to electrical shock, disconnect the electrical power before electrically connecting the unit.

Thermostat Wiring

When an electric heater is installed, the thermostat wiring will be made at the heater accessory box.

If a unit is installed without electric heaters, the low voltage wiring can be made at the control box.

See the unit wiring diagram for electrical connections.





Figure 2
Typical Thermostat and Unit 24 Volt Wiring Hookup

Electrical Connections

Note: The units are designed for operation on 60 Hz current and at the voltages shown on the rating plate. All internal wiring in the unit is complete. The power supply maybe brought into the contactor (refer to unit wiring diagram supplied with unit). Ensure 24 volt wiring is connected between the unit control panel and the room thermostat. Refer to Figure 2 for proper thermostat wiring and Figure 3 for location of the low voltage terminal board.

Refer to the unit wiring diagram for electrical connections. When installed, the unit must be electrically grounded in accordance with local codes or in the absence of local codes, with the National Electrical Code, ANSI/NFPA No. 70, and/or the CSA C22.1 Electrical Code, if an external source is utilized.



WARNING

To avoid death or personal injury due to electrical shock, wiring to the unit must be properly grounded.



CAUTION

To avoid personal injury or property damage due to fire, use only copper conductors.



CAUTION


To prevent improper and dangerous operation due to wiring errors, label all wires prior to disconnection when servicing controls. Verify proper operation after servicing.

The best protection for the wiring is the lowest rated fuse or circuit breaker which will supply power to the unit during normal operation without nuisance trips. Such a device will provide maximum circuit protection. **DO NOT EXCEED THE MAXIMUM OVERCURRENT DEVICE SIZE SHOWN ON UNIT DATA PLATE.**

All line voltage connections must be made through weatherproof fittings. All exterior power supply and ground wiring must be in approved weatherproof conduit. Low voltage wiring from the unit control panel to the thermostat requires coded cable.

FLEXIBLE WIRING SETUP WITH ELECTRIC HEATER

Line and low voltage wiring can enter the unit from either side.



For knockout locations, see dimension drawing on the Specification Sheet. Use the Single Point wiring kit to add further flexibility to the installation wiring.

Unit Voltage

The unit transformer is factory connected for 230V operation. If the unit is to operate on 208V, reconnect the transformer primary lead as shown on the unit wiring diagram.

VI. Circulating Air and Filters

Airflow Conversion

Units can easily be converted from horizontal to vertical airflow delivery.

Units are shipped from the factory ready for horizontal airflow. If conversion to vertical airflow is necessary, proceed as follows:

1. Cut insulation around bottom openings and remove panels from the bottom of the unit, saving the screws holding the panels in place.
2. From the rear of the unit, remove the four screws securing the blower assembly in place and loosen the two screws directly below the duct opening (Figure 4).
3. Remove the clamp securing the blower assembly to the bottom of the unit. The clamp and screws may be discarded (Figure 5).
4. Rotate the blower assembly 90° clockwise, setting the blower assembly outlet on the bottom of the unit and secure with two screws removed in step 2 (Figure 6).
5. Tighten the two screws below the duct opening that were loosened in step 2.




Figure 4
Duct Removal




Figure 5
Clamp Removal




Figure 6
Vertical Blower Assembly

Use the Horizontal Duct Cover Kit (CHK001A) to complete the conversion.

For 24, 30, 36, and 42 Models:

1. Remove and set aside the four supply air side screws (Figure 7).
2. Remove and set aside the two return air side screws.
3. Center flange bracket (Figure 8) and unit openings. Attach flange brackets to the unit using the removed screws in Step 1. Retighten screws.
4. Drill two 1/8" diameter holes on the return air side as indicated in Figure 8.
5. Secure the return air side flange bracket with the two self-tapping screws included with the unit.




Figure 7
Supply Air Side Screws Location




Figure 8
Flange Bracket Location

NOTE: If Horizontal Duct Cover kits are required, align the horizontal duct covers (Figure 9) over the flange brackets just installed and secure with screws included in the Horizontal Duct Cover kit.




Figure 9
Horizontal Duct Cover Alignment

Ductwork

Duct systems and register sizes must be properly designed for the C.F.M. and external static pressure rating of the unit. Ductwork should be designed in accordance with the recommended methods of Air Conditioning Contractors of America Manual D (Residential) or Manual Q (Commercial). All ductwork exposed to the outdoors must include a weatherproof barrier and adequate insulation.

A duct system should be installed in accordance with Standards of the National Board of Fire Underwriters for the Installation of Air Conditioning, Warm Air Heating and Ventilating Systems. Pamphlets No. 90A and 90B.

The warm air supply duct from the unit through a wall fabricated of combustible material may be installed without clearance. However, minimum clearances for the unit must be observed as shown in Specification Sheet.

The outlet duct should be provided with an access panel.

For vertical airflow, the ductwork should be attached to the roof curb prior to installing the unit. Ductwork dimensions are shown in the Amana PRC roof curb installation manual.

If desired, supply and return duct connections to the unit may be made with flexible connections to reduce possible unit operating sound transmission.

Filters



CAUTION

To prevent property damage due to fire and loss of equipment efficiency or equipment damage due to dust and lint build up on internal parts, never operate unit without a filter installed.

Even though a return air filter is not supplied with this unit, there must be a means of filtering all return air.

Refer to Specification Sheet provided with unit for filter size information.

If using the Over/Under Transition Kit, the filter(s) may be located in the return air duct(s) or return air filter grille(s). Filters installed external to the unit should be sized in accordance with their manufacturer recommendations. A throwaway filter must be sized for a maximum face velocity of 300 feet per minute.

FILTER INSTALLATION

Important: When installing a filter, the air flow arrows on the filter must point toward the circulating air blower.

VII. Condensate Drain

CONDENSATE DRAIN CONNECTION

This unit has a built-in trap - no external trap is required; the drain may be extended using 3/4" PVC piping.

VIII. Normal Sequence of Operations

NOTE: There is a fan delay on initial power to unit before the low voltage board resets and is operational.

COOLING

1. Thermostat calls for cooling. The compressor and outdoor fan start.
2. Thirty seconds later, the indoor fan starts and cool air is delivered to the conditioned space until the thermostat is satisfied.
3. After the thermostat is satisfied, the compressor and outdoor fan shut off; 30 seconds later, the indoor fan shuts off.

NOTE: The extra fan time allows additional cooling from the indoor coil to be transferred to the conditioned space.

Heating (Electric)

1. Thermostat calls for heating.
2. Thirty seconds later, the indoor fan starts and heat is delivered to the conditioned space until the thermostat is satisfied.
3. In another 30 seconds, the indoor fan shuts off.

IX. Startup and Adjustment



CAUTION

This unit must not be used as a "construction heater" during the finishing phases of construction on a new structure. This type of use may result in premature failure of the unit due to extremely low return air temperatures and exposure to very dirty atmospheres.

Compressor Protection Device

The PCC**C compressor includes components which are designed to protect the compressor against abnormal operating conditions.



WARNING

To avoid death or personal injury, always disconnect electrical power before inspecting or servicing the unit. All compressor protection devices reset automatically, energizing the contactor and outdoor fan.

Operating Instructions

1. Turn on the electrical power supply to the unit.
2. Place the room thermostat selector switch in the COOL or HEAT position (or AUTO if available, and if automatic changeover from cooling to heating is desired).
3. Set the room thermostat to the desired temperature.

X. Maintenance



WARNING

To avoid death or personal injury due to electrical shock, disconnect electrical power before performing any maintenance.

Replacing Or Cleaning Filter

A return air filter is not supplied with this unit; however, there must be a means of filtering all of the return air. The filter(s) may be located in the return air duct(s), or return air filter grille(s). Consult with your installing dealer for the actual location of the return air filter(s) for your unit.

Dirty filters are the most common cause of inadequate heating or cooling performance. Filter inspection should be made at least every two months; more often if necessary because of local conditions and usage.

Dirty throwaway filters should be discarded and replaced with a new, clean filter. Dirty permanent filters should be washed with water, thoroughly dried and sprayed with a filter adhesive before being reinstalled. (Filter adhesives may be found at many hardware stores.) Permanent filters should last several years; however, should one become torn or uncleanable, it should be replaced.

Maintaining Cabinet Finish

Use a fine grade automotive wax on the cabinet finish to maintain the finish's original high luster. This is especially important in areas with high ultraviolet radiation.

Clean Outside Coil (Qualified Servicer Only)

The coil with the outside air flowing over it should be inspected annually and cleaned as frequently as necessary to keep the finned areas free of lint, hair and debris.

Condenser and Evaporator Motors

Bearings on the evaporator motor and the condenser motor are permanently lubricated. No additional oiling is required.



WARNING

To avoid death or personal injury due to electrical shock, do not remove any internal compartment covers or attempt any adjustment.



CAUTION

Verify proper operation after servicing.

XI. Accessories

Accessory

Horizontal Duct Covers (CHK001A)
Single Point Power Connection (SPK**A)
Roof Curb - Heat Pump/AC (PRC06A1)
Roof Curb - Universal (PRC08A1)
Over-Under to Side by Side PDTR04A

Heater Capacity @ 240 VAC

Heater Kit	Kw	BTUH	Minimum Circuit Ampacity		Maximum Overcurrent Protection	
			L1-L2	L3-L4	L1-L2	L3-L4
PHCB05C1	5.0	16,400	25	--	30	--
PHCB10C1	10.0	32,800	50	--	60	--
PHCB15C1	15.0	49,100	50	25	60	30
PHCB20C1	20.0	65,600	50	50	60	60

Additional Amana accessories, as described above, can be purchased to fit specific application needs. Accessories can be ordered by the part numbers in the table and each accessory includes its own separate instructions.

Replacement Parts

Refer to the description in the Parts Catalog when ordering any part. Be sure to provide the unit model, manufacturing, and serial numbers with the order.

Note: Details for installing and wiring electric heater kits and single point wiring kits are contained in the installation instructions for these accessories.